



PJ3500LCD

USER MANUAL
VOLUME1



File Name: PJ3500LCD_ITA_1.0.indb

Version: 1.0

Date: 09/09/2016

Revision History

Date	Version	Reason	Editor
09/09/2016	1.0	First Version	J. H. Berti

PJ3500LCD - User Manual
Version 1.0

© Copyright 2016
R.V.R. Elettronica SpA
Via del Fonditore 2/2c - 40138 - Bologna (Italia)
Telephone: +39 051 6010506
Fax: +39 051 6011104
Email: info@rvr.it
Web: www.rvr.it

All rights reserved

Printed and bound in Italy. No part of this manual may be reproduced, memorized or transmitted in any form or by any means, electronic or mechanic, including photocopying, recording or by any information storage and retrieval system, without written permission of the copyright owner.

Declaration of Conformity

Hereby, R.V.R. Elettronica SpA, declares that this FM transmitter is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.










WARNING



The following information is needed in order to perform the change of output power.
The non-respect of this content may cause damage to the equipment or to the people.
Menus and images are for illustration purposes only and may differ from reality.



1. Startup procedure TX with PJ3500LCD GREEN LINE amplifiers

N.	Operation	Result
1	Turn ON the exciter using the front switch	
2	Set the output power of the exciter to zero.	
3	Set the exciter frequency to the working value	
4	Turn on the amplifier using the front switch	
5	Set the amplifier on LOCAL: press "ESC" key then select "Fnc" menu then change to LOCAL if necessary.	
6	Press "ESC" key until the display shows the main screen (FWD and RFL readings)	
7	On amplifier, press "Enter" key and keep it pressed until the display shows "Set: "	 
8	Adjust the bar to mid scale using the arrow keys and press the "Enter" key.	 
9	Put the output power of the exciter verifying that PA has at least 30W . To check it press "ESC" key then select "Pwr" menu then press down arrow to visualize the measure.	
10	Press "ESC" key until the display shows the main screen (FWD and RFL readings)	
11	Following the procedure on point (7), slowly raise the power output of amplifier until reaching the desired value.	
12	After ten minutes, readjust the output power of the amplifier, it will be lowered due to heating.	
13	Set the amplifier on REMOTE: press "ESC" key then select "Fnc" menu then change to REMOTE if necessary.	
14	Repeat the procedure if the carrier frequency is changed.	



DECLARATION OF CONFORMITY

We, the undersigned,

Manufacturer's Name:

R.V.R. Elettronica SpA

Manufacturer's Address:

Via del Fonditore 2/2c
Zona Ind. Roveri
40138 Bologna
Italy

Certify and declare under our sole responsibility that the product:

Product Description:

FM Solid State Amplifier for Broadcast service

Models:

PJ3500LCD

Variants:

/

Frequency Range:

87.5 ÷ 108.0 MHz

RF Power Output:

350 ÷ 3500 W

when used for its intended purpose, is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/CE "R&TTE", and therefore carries the "CE" mark.

The conformity assessment procedure referred in Article 10 and detailed in Annex III of Directive 1999/5/EC has been followed.

The following harmonized standard have been applied:

ElectroMagnetic Compatibility (3.1b): EN 301 489-1 V1.9.2 (2011-09) +
EN 301 489-11 V1.3.1 (2006-05)

Safety (3.1a): EN 60215 (2016-04) +
EN 60065 (2014-12)

The technical documentation is held at the location above, as required by the conformity assessment procedure.

Bologna, Italy, 07/07/2016


Ravagnani Stefano
Technical Manager
R.V.R. Elettronica S.p.A.



Technical Specification

		PJ3500LCD		
<i>Parameters</i>	<i>Conditions</i>	<i>U.M.</i>	<i>Value</i>	
GENERALS				
Frequency range		MHz	87.5 ÷ 108	
Rated output power		W	3500	
Spurious & harmonic suppression		dBc	<82 (85 typical)	Meets or exceeds all FCC and CCIR rules
Ambient working temperature		°C	0 to + 50 (operational -10)	
POWER REQUIREMENTS				
Power supply type			monophase/threephases Y	
AC Power Input	AC Supply Voltage	VAC	230 +10% -15% (*) 400 +10% -15% (**)	(*) monophase (**) Threephases Y
	AC Apparent Power Consumption	VA	4996	
	Active Power Consumption	W	4987	
	Overall efficiency	%	Typical 70	
	Power Factor		0,998	
DC Power Input	Connector		Terminal Block	
	DC Supply Voltage	VDC		
	DC Current	ADC		
MECHANICAL DIMENSIONS				
Physical Dimensions	Front panel width	mm	483 (19")	19" EIA rack
	Front panel height	mm	132	
	Overall depth	mm	670	
	Chassis depth	mm	650	
Weight		kg	about 31	
VARIOUS				
Cooling type			Forced, with internal fan	
Potenza dissipata in calore		W	500	
Acoustic Noise		dBA	<75	Leq 3 min @ 1 m
RF INPUT				
RF Input	Connector		N type	
	Impedance	Ohm	50	
Driver power for rated output		W	30	
Max input power before protection		W	35	
RF OUTPUTS				
RF Output	Connector		7/8" EIA	
	Impedance	Ohm	50	
RF Monitor	Connector		BNC	
	Impedance	Ohm	50	
	Output Level	dB	approx. -60	Referred to the RF output
AUXILIARY CONNECTIONS				
Interlock	Connector		2 x BNC	For remote power inhibition (short is RF off)
Service	Connector		DB9 F	Factory reserved for firmware program
I ² Cbus	Connector		DB9 F	
Telemetry Interface	Connector		DB25F	
FUSES				
On Mains			3 External F 10 T - 6 x 30 mm	
On services				
On PA Supply			4 Internal F 32 A 10 x 38 mm	
On Aux VDE socket				
HUMAN INTERFACE				
Input device			4 pushbutton	
Display			Alphanumeric LCD - 2 x 16	

Table of Contents

1.	Preliminary Instructions	1
2.	Warranty	1
3.	First Aid	2
3.1	Treatment of electrical shocks	2
3.2	Treatment of electrical Burns	2
4.	General Description	3
4.1	Unpacking	3
4.2	Features	3
4.3	Frontal Panel Description	5
4.4	Rear Panel Description	6
4.5	Connectors Pinouts	7
5.	Quick guide for installation and use	9
5.1	Preparation	9
5.2	First power-on and setup	11
5.3	Operation	13
5.4	Management Firmware	15
6.	Identification and Access to the Modules	23
6.1	Upper view PJ3500LCD	23
6.2	Lower view PJ3500LCD	24
7.	Working Principles	25
7.1	Panel Board	25
7.2	Interface Board	25
7.3	External Telemetry Board	26
7.4	PWR Input Measure Board	26
7.5	Power Supply	26
7.6	Power Amplifier	26
7.8	LPF Card	27
7.9	Bias Card	27

IMPORTANT



The symbol of lightning inside a triangle placed on the product, evidences the operations for which is necessary gave it full attention to avoid risk of electric shocks.



The symbol of exclamation mark inside a triangle placed on the product, informs the user about the presence of instructions inside the manual that accompanies the equipment, important for the efficacy and the maintenance (repairs).

1. Preliminary Instructions

• General Warnings

This equipment should only be operated, installed and maintained by "trained" or "qualified" personnel who are familiar with risks involved in working on electric and electronic circuits. "Trained" means personnel who have technical knowledge of equipment operation and who are responsible for their own safety and that of other unqualified personnel placed under their supervision when working on the equipment.

"Qualified" means personnel who are trained in and experienced with equipment operation and who are responsible for their own safety and that of other unqualified personnel placed under their supervision when working on the equipment.

⚡ WARNING: Residual voltage may be present inside the equipment even when the ON/OFF switch is set to Off. Before servicing the equipment, disconnect the power cord or switch off the main power panel and make sure the safety earth connection is connected. Some service situations may require inspecting the equipment with live circuits. Only trained and qualified personnel may work on the equipment live and shall be assisted by a trained person who shall keep ready to disconnect power supply at need.

R.V.R. Elettronica S.p.A. shall not be liable for injury to persons or damage to property resulting from improper use or operation by trained/untrained and qualified/unqualified persons.

⚡ WARNING: The equipment is not water resistant. Any water entering the enclosure might impair proper operation. To prevent the risk of electrical shock or fire, do not expose this equipment to rain, dripping or moisture.

Please observe local codes and fire prevention rules when installing and operating this equipment.

⚡ WARNING: This equipment contains exposed live parts involving an electrical shock hazard. Always disconnect power supply before removing any covers or other parts of the equipment.

Ventilation slits and holes are provided to ensure reliable operation and prevent overheating; do not obstruct or cover these slits. Do not obstruct the ventilation slits under any circumstances. The product must not be incorporated in a rack unless adequate ventilation is provided or the manufacturer's instructions are followed closely.

⚠ WARNING: This equipment can radiate radiofrequency energy and, if not installed in compliance with manual instructions and applicable regulations, may cause interference with radio communications.

⚠ WARNING: This equipment is fitted with earth connections both in the power cord and for the chassis. Make sure both are properly connected.

Operation of this equipment in a residential area may cause radio interference, in which case the user may be required to take adequate measures.

The specifications and data contained herein are provided for information only and are subject to changes without prior notice. **R.V.R. Elettronica S.p.A.** disclaims all warranties, express or implied. While **R.V.R. Elettronica S.p.A.** attempts to provide accurate information, it cannot accept responsibility or liability for any errors or inaccuracies in this manual, including the products and the software described herein. **R.V.R. Elettronica S.p.A.** reserves the right to make changes to equipment design and/or specifications and to this manual at any time without prior notice.

• Notice concerning product intended purpose and use limitations.

This product is a radio transmitter suitable for frequency-modulation audio radio broadcasting. Its operating frequencies are not harmonised in designated user countries. Before operating this equipment, user must obtain a licence to use radio spectrum from the competent authority in the designated user country. Operating frequency, transmitter power and other characteristics of the transmission system are subject to restrictions as specified in the licence.

2. Warranty

La **R.V.R. Elettronica S.p.A.** warrants this product to be free from defects in workmanship and its proper operation subject to the limitations set forth in the supplied Terms and Conditions. Please read the Terms and Conditions carefully, as purchase of the product or acceptance of the order acknowledgement imply acceptance of the Terms and Conditions. For the latest updated terms and conditions, please visit our web site at WWW.RVR.IT. The web site may be modified, removed or updated for any reason whatsoever without prior notice. The warranty will become null and void in the event the product enclosure is opened, the product is physically damaged, is repaired by unauthorised persons or is used for purposes other than its intended use, as well as in the event of improper use, unauthorised changes or neglect. In the event a defect is found, follow this procedure:

- 1 Contact the seller or distributor who sold the equipment; provide a description of the problem or malfunction for the event a quick fix is available.

Sellers and Distributors can provide the necessary information to troubleshoot the most frequently encountered problems. Normally, Sellers and Distributors can offer a faster repair service than the Manufacturer would. Please note that Sellers can pinpoint problems due to wrong installation.

- 2 If your Seller cannot help you, contact **R.V.R. Elettronica S.p.A.** and describe the problem; if our staff deems it appropriate, you will receive an authorisation to return the equipment along with suitable instructions;
- 3 When you have received the authorisation, you may return the unit. Pack the unit carefully before shipment; use the original packaging whenever possible and seal the package perfectly. The customer bears all risks of loss (i.e., **R.V.R.** shall not be liable for loss or damage) until the package reaches the **R.V.R.** factory. For this reason, we recommend insuring the goods for their full value. Returns must be sent on a C.I.F. basis (PREPAID) to the address stated on the authorisation as specified by the **R.V.R.** Service Manager.



Units returned without a return authorisation may be rejected and sent back to the sender.

- 4 Be sure to include a detailed report mentioning all problems you have found and copy of your original invoice (to show when the warranty period began) with the shipment.

Please send spare and warranty replacement parts orders to the address provided below. Make sure to specify equipment model and serial number, as well as part description and quantity.



R.V.R. Elettronica S.p.A.
Via del Fonditore, 2/2c
40138 BOLOGNA ITALY
Tel. +39 051 6010506

3. First Aid

All personnel engaged in equipment installation, operation and maintenance must be familiar with first aid procedures and routines.

3.1 Electric shock treatment

3.1.1 If the victim is unconscious

Follow the first aid procedures outlined below.

- Lay the victim down on his/her back on a firm surface.
- the neck and tilt the head backwards to free the airway system (**Figure 1**).




Figure 1

- If needed, open the victim's mouth and check for breathing.
- If there is no breathing, start artificial respiration without delay (**Figure 2**) as follows: tilt the head backwards, pinch the nostrils, seal your mouth around the victim's mouth and give four fast rescue breaths.



Figure 2

- Check for heartbeat (**Figure 3**); if there is no heartbeat, begin chest compressions immediately (**Figure 4**) placing your hands in the centre of the victim's chest (**Figure 5**).




Figure 3




Figure 4




Figure 5

- One rescuer: give 2 quick rescue breaths after each 15 compressions.
- Two rescuers: one rescue breath after each 5 compressions.

- Do not stop chest compressions while giving artificial breathing.
- Call for medical help as soon as possible.

3.1.2 If the victim is conscious

- Cover victim with a blanket.
- Try to reassure the victim.
- Loosen the victim's clothing and have him/her lie down.
- Call for medical help as soon as possible.

3.2 Treatment of electric burns

3.2.1 Large burns and broken skin

- Cover affected area with a clean cloth or linen.
- Do not break any blisters that have formed; remove any clothing or fabric that is stuck to the skin; apply adequate ointment.
- Administer adequate treatment for the type of accident.
- Get the victim to a hospital as quickly as possible.
- Elevate arms and legs if injured.

If medical help is not available within an hour, the victim is conscious and is not retching, administer a solution of table salt and baking soda (one teaspoon of table salt to half teaspoon of baking soda every 250 ml of water).

Have the victim slowly drink half a glass of solution for four times during a period of 15 minutes.

Stop at the first sign of retching.

Do not administer alcoholic beverages.

3.2.2 Minor burns

- Apply cold (not ice cold) strips of gauze or dress wound with clean cloth.
- Do not break any blisters that have formed; remove any clothing or fabric that is stuck to the skin; apply adequate ointment.
- If needed, have the victim change into clean, dry clothing.
- Administer adequate treatment for the type of accident.
- Get the victim to a hospital as quickly as possible.
- Elevate arms and legs if injured.

4. General Description

The **PJ3500LCD** is an **radio broadcasting amplifier** manufactured by **R.V.R. Elettronica SpA** featuring adjustable RF power output up to 3500 W under 50 Ohm standard load and less than 28/30 W drive power requirement.

The **PJ3500LCD** is designed to being contained into a 19" rack box of 3HE.

4.1 Unpacking

The package contains:

- 1 **PJ3500LCD**
- 1 User Manual

The following accessories are also available from Your R.V.R. Dealer:

- **Accessories, spare parts and cables**

4.2 Features

The overall efficiency of **PJ3500LCD** is better than 70% across the bandwidth, for this reason are part of **RVR Green Line** family.

This performance characteristic is guaranteed in a range between +0.25 dB and -3 dB (+5% and -50%) referred to the nominal power of the equipment: for example from 1750W to 3675W in case of **PJ3500LCD**; outside these limits the equipment is able to work properly but can not guarantee an efficiency of 70%.

The operating logic during the output power regulation, which is necessary in order to not deteriorate the efficiency even of 5-6%, expects to set the pilot power to the optimum power (dependent on the amplifier: for example the **PJ3500LCD** requires 27/28 W) and then successively adjust the bar setting of power on amplifier in order to obtain the desired output power.

The amplifier incorporates a low-pass filter to keep harmonics below the limits provided for by international standards (CCIR, FCC or ETSI).



Two major features of **PJ3500LCD** are compact design and user-friendliness. Another key feature is its modular-concept design: the different functions are performed by modules with most connections achieved through male and female connectors or through flat cables terminated by connectors. This design facilitates maintenance and module replacement.

The RF power section of **PJ3500LCD** uses four LD-MOSFET modules delivering up to 900W output power each.

An LCD on the front panel and a push-button panel provide for user interfacing with the microprocessor control system, which implements the following features:

- Output power setup.
- Power output enable/disable.
- User-selectable threshold settings for output power alarm (Power Good feature)
- Measurement and display of transmitter operating parameters.
- Communication with external devices such as programming or telemetry systems via RS232 serial interface or I²C.

Four LEDs on the front panel provide the following status indications: **ON**, **FAULT**, **FOLDBACK** and **RF MUTE**.

The amplifier management firmware is based on a menu system. User has four navigation buttons available to browse submenus: **ESC** ,  ,  , and **ENTER**.


The rear panel features the mains input connectors, RF power input and output connectors, remote connector, protection fuse, interlock input and interlock output connectors and a BNC connector that provides an RF test point with level being -60dBc lower than power output.



IMPORTANT: *The equipment works in three-phase, with a star center connection, and can also be used in single-phase.*

4.3 Frontal Panel Description


4.3.1 Frontal Panel Description of PJ3500LCD



- | | |
|---------------|---|
| [1] ON | Green LED - Turns on when amplifier is powered on. |
| [2] FAULT | Red LED, lit on in presence of a fault that can not be resolved automatically. |
| [3] FOLDBACK | Yellow LED - Turns on when foldback current limiting (Automatic Gain Control) is intervened. |
| [4] R.F. MUTE | Yellow LED, lit on when the amplifier's power output is inhibited by an external interlock command. |
| [5] CONTRAST | Display contrast adjusting trimmer. |
| [6] POWER | AC mains ON/OFF switch. |
| [7] ESC | Press this button to exit a menu. |
| [8] | Navigation button used to browse menu system and edit parameters. |
| [9] | Navigation button used to browse menu system and edit parameters. |
| [10] ENTER | Press this button to confirm a modified parameter and open a menu. |
| [11] DISPLAY | Liquid Crystal Display. |
| [12] AIR FLOW | Grid for the intake of the air flow of the forced ventilation. |

4.4 Rear Panel Description

4.4.1 Rear Panel Description of PJ3500LCD




- | | |
|---------------------------|---|
| [1] AIR FLOW | Grid for the intake of the air flow of the forced ventilation. |
| [2] INTERLOCK OUT | Interlock output BNC connector: to inhibit an external device, as an exciter. In case of fault, the inner connector is shorted to ground. |
| [3] REMOTE | DB25 connector for telemetry of the machine. |
| [4] FUSE R | Mains supply fuse. |
| [5] SERVICE | Reserved for future implementations. |
| [6] FUSE T | Mains supply fuse. |
| [7] FUSE S | Mains supply fuse. |
| [8] R.F. INPUT | RF input connector, N-type. |
| [9] R.F. OUTPUT | RF output connector, 7/8" EIA flange. |
| [10] SERVICE | DB9 connector for interconnection with other devices and for factory parameters programming (only for factory programming). |
| [11] FWD AGC | Trimmer to set output power limitation according to FWD fold input. |
| [12] MODEM | Normally not used. |
| [13] COMMON BUS | DB15 connector for interconnection with other devices. |
| [14] RS232 | Normally not used. |
| [15] L ADJ | Normally not used. |
| [16] R ADJ | Normally not used. |
| [17] TOSLINK | Normally not used. |
| [18] I ² C BUS | DB9 connector for I ² C bus networking. |
| [19] AES/EBU | Normally not used. |
| [20] INTERLOCK IN | Interlock input BNC connector: to inhibit the amplifier from an external device, like an exciter. |
| [21] MAINS | Mains supply connectors, 230 V 50-60 Hz. |

4.5 Connectors Pinouts

4.5.1 Remote

Type: Female DB25



1	NC	
2	RF power amplifier voltage	3,9V x 40V
3	GND	GND
4	Reflected Power	3.9V x 350W
5	Interlock Out	Signals the activation by grounding the contact normally open
6	NC	
7	GND	GND
8	"On" Command	A pulse to ground (500 ms) turn on the equipment
9	Set 1 (FWD Power Good 1)	
10	WAIT	Signals the activation by grounding the contact normally open
11	Reset alarm	
12	OFF	Telesignalling of equipment turned off
13	Interlock	Signals the activation by grounding the contact normally open
14	NC	
15	RF power amplifier current	3.9V x 120 A
16	Forward Power	3.9V x 3500W
17	FAULT	Signals the activation by grounding the contact normally open
18	Set 3 (RFL Power Good 3)	
19	Input Power	3.9V x 40W
20	"OFF" Command	A pulse to ground (500 ms) turn off the equipment
21	GND	GND
22	Set 2 (FWD Power Good 2)	
23	LOC	Signals the activation by grounding the contact normally open
24	+Vcc	
25	ON	Telesignalling of equipment turned on

4.5.2 I²C Bus


Type: Male DB9



1	NC	
2	SDA	Serial DATA
3	SCL	Serial CLock
4	NC	
5	GND	GND
6	NC	
7	NC	
8	NC	
9	NC	

4.5.3 Service (for programming of factory parameters)


Type: Female DB9



1	NC
2	TX_D
3	RX_D
4	Internally connected with 6
5	GND
6	Internally connected with 4
7	Internally connected with 8
8	Internally connected with 7
9	NC

4.5.4 COM BUS

Type: Male DB15



1	GND
2	NC
3	NC
4	NC
5	PWR REG
6	NC
7	NC
8	NC
9	NC
10	NC
11	NC
12	NC
13	NC
14	NC
15	NC

5. Quick guide for installation and use

This section provides a step-by-step description of equipment installation and configuration procedure. Follow these procedures closely upon first power-on and each time any change is made to general configuration, such as when a new transmission station is added or the equipment is replaced.

Once the desired configuration has been set up, no more settings are required for normal operation; at each power-up (even after an accidental shutdown), the equipment defaults to the parameters set during the initial configuration procedure.

The topics covered in this section are discussed at greater length in the next sections, with detailed descriptions of all hardware and firmware features and capabilities. Please see the relevant sections for additional details.



IMPORTANT: When configuring and testing the transmitter in which the equipment is integrated, be sure to have the Final Test Table supplied with the equipment ready at hand throughout the whole procedure; the Final Test Table lists all operating parameters as set and tested at the factory.

5.1 Preparation

5.1.1 Preliminary checks

Unpack the amplifier and immediately inspect it for transport damage. Ensure that all connectors are in perfect condition.

The main fuse can be accessed from the outside on the rear panel. Extract the fuse carrier with a screwdriver to check its integrity or for replacement, if necessary.

The following fuses are used:

	PJ3500LCD @ 230 Vac
Main power supply	(3x) 10A type 6x30

Table 5.1: Fuse

Provide for the following (applicable to operating tests and putting into service):

- ✓ Single phase mains power supply 230 VAC ($\pm 15\%$) for **PJ3500LCD**, with adequate earth connection.
- ✓ For operating tests only: dummy load with 50 Ohm impedance and adequate capacity (3500W for **PJ3500LCD** as a minimum).

- ✓ Connection cable kit including:
 - Mains power cable.
 - Coaxial cable with BNC connectors for interlock signal connection between exciter and amplifier.
 - RF cable for output to load / antenna (50 Ohm coaxial cable with standard 7/8" connector).

5.1.2 Connections

Connect the output of a suitable FM exciter (for instance, PTX30LCD exciter available from R.V.R. Elettronica) to the RF input using a 50 Ohm coaxial cable with "N"-type connectors. To begin with, set exciter to minimum output power and switch it off.

Connect the amplifier INTERLOCK OUT output to the matching INTERLOCK IN input fitted on all R.V.R. Elettronica exciters as standard; if your exciter is a different brand, identify an equivalent input.

Connect the RF output to an adequately rated dummy load or to the antenna.

The diagram of RF connection and control between the amplifier and its exciter and connection with the load, is represented in Figure 5.2.




Figure 5.1: connections with amplifier



WARNING: Electric shock hazard! Never handle the RF output connector when the equipment is powered on and no load is connected. Injury or death may result.

Ensure that the **POWER** switch on the front panel is set to "OFF".

Connect the mains power cable to the MAINS connector on the rear panel.



Note : *The mains must be equipped with adequate ground connection properly connected to the machine. This is a pre-requisite for ensuring operator safety and correct operation.*



WARNING: The power supply connector is a terminal board. Ensure the wire is not live before performing the connection.

5.2 First power-on and setup

Follow this procedure upon first power-on and after making changes to the configuration of the transmitter in which the amplifier is integrated.



Note : *Standard factory settings are RF output power disabled (**Pwr OFF**) and regulated output power set to lower limit (unless otherwise specified by customer).*

5.2.1 Pilot exciter setup

Set up the pilot exciter so that the output power it delivers to a matched load equals the maximum input power indicated in the amplifier **final test table**, switch off the exciter and connect it to the amplifier.



IMPORTANT: *to obtain the maximum efficiency, place the excitation power to a 25W as minimum (28W recommended).*

5.2.2 Exciter frequency setup

Set the operating frequency in according to your needs, switch off the exciter and connect it to the amplifier.

5.2.3 Power-on

When you have performed all of the connections described in the previous paragraph, power on the amplifier using the suitable power switch on the front panel. Also, switch on the pilot exciter.

5.2.4 Power check

Ensure that the **ON** light turns on. Machine name should appear briefly on the display, quickly followed by forward and reflected power readings. If RF output is disabled, these readings will be zero.

5.2.5 How to enable Local mode and the RF output

Check current mode setting and enable Local mode (if not already enabled) following menu path **Fnc** ⇒ **Loc** ⇒ **Local**: if left disabled, the machine will not accept the next commands.

Check current RF output setting and enable output (if not already enabled) following menu path **Fnc** ⇒ **Pwr** ⇒ **ON**.

Check output power level and set to maximum level (if not already set to maximum) from the Power Setup Menu, which you can call up by pressing these keys in the order: ESC (opens Default Menu) ⇒ ENTER (hold down for 2 seconds) ⇒ SET ⇒ use key to set bar to maximum limit.



5.2.6 RF output power level control



IMPORTANT: *The amplifier incorporates Automatic Gain Control and output power is modulated based on the power level set by the user and actual operating conditions, such as temperature, reflected power and other parameters. Drive power must be kept steady at maximum output power capacity. Please read next section for more details of RF power modulation.*

Open the **Power Setup Menu** pressing the following keys in the order:

ESC (opens **Default Menu**) ⇒ **ENTER** (hold down for 2 seconds).

Use the keys  and  in the **SET** menu to set amplifier output power; the setting bar at the side of **SET** provides a graphic indication of power setting; please consider that the forward power readout provided on the display (**FWD: xxxx W**) reflects actual output power reading, **which may be lower than regulated power supply when Automatic Gain Control is running in power supply limitation mode** (please read next section about RF power supply modulation for more details).



Note : *Output power can also be set in a **Pwr OFF** condition; in this condition, (**Fwd**) output power reading on the display will be 0 (zero), whereas the **SET** bar, which you can control using the keys, provides a graphic display of the amount of power that will be delivered the moment you switch back to **Pwr On** state.*

5.2.7 Adjustment of setting in the piloting exciter

Adjust the piloting exciter so that it delivers an output power, on adapted load, equal to the maximum input power of the amplifier, as shown in the **Final Test Table**.



IMPORTANT: *put the minimum excitation power at 25W to have the maximum efficiency (28W recommended)..*

5.2.8 Adjustment of RF output power level control

Open the **Power setup menu**, pressing the following keys in the order:

ESC (opens **Default Menu**) \Rightarrow **ENTER** (hold down for 2 seconds). .

Use the keys  and  in the **SET** menu to set amplifier output power.

For combined amplifiers, increase the power alternately on both. This is to avoid high values of unbalanced power (**Rej Pwr**) on the combiner.



Note: recheck the output power of transmitter system after ten minutes and, if necessary, repeat the operations described above to adjust it. A decline in the value of equipment is possible due to heat shock or special working conditions.

5.2.9 Changing the *Power Good* alarm threshold

Change Forward Power Good alarm setting **PgD** from the **Fnc** menu as desired (factory setting is 50%).

5.2.10 Setting equipment I²C address

Change the **IIC** address in the **MIX** (Miscellaneous) menu as desired (factory setting is 01).

5.2.11 How to enable Remote mode

If you wish to use the telemetry control feature, enable Remote control in the **Fnc** menu.



Note : In the **Remote** mode, all local push-button controls except **Remote/Local** for switching back to Local mode) are disabled . Operating parameter readings are available.

5.3 Operation



NOTE: For better clarity, only the typical screens of **PJ3500LCD** are reported below.

- 1) Power on the amplifier and ensure that the **ON** light turns on. Machine name should appear briefly on the display, quickly followed by forward and reflected power readings (Menu 1), provided that the amplifier is delivering output power.

```

Fwd:  3.42  kW
Rf1:   12    W
  
```

Menu 1

- 1b) To **modify power level setting**, hold down the **ENTER** button until opening the **power setup menu**.

The edit screen will look like this:



```

SET: |||||
Fwd:  3.42  kW
  
```

Menu 2

Next to **SET** indication, a bar provides a graphic display of preset output power. The filled portion of the bar is proportional to set power level.

<i>Example</i>		
100% output power	Full bar	≅ 3500W in output (mod.PJ3500LCD)
50% output power	Half bar	≅ 1750W in output (mod.PJ3500LCD)
25% output power	1/4 bar	≅ 875W in output (mod.PJ3500LCD)

The bottom line provides instantaneous power reading (3.42W in this instance, and falling below 1.60kW the reading back in Watts. Going up the power, for an hysteresis effect, exceeding 1400W the reading returns in kWatt) ; press button  to increase level, press  to decrease it. When you have achieved the desired level, press **ENTER** to confirm and exit the default menu. Please note that the setting is stored automatically; in other words, if you press **ESC** or do not press any keys before the preset time times out, the latest power level set will be retained.



NOTE: This feature prevents the machine from delivering maximum power as soon as output is enabled from menu 4, or in the event the machine is already set to **ON** and energised.

- 2) Ensure that machine is not in a locked-out state. Press the **ESC** key to call up the selection screen (Menu 3). Highlight **Fnc** and press **ENTER** to confirm and access the appropriate menu (Menu 4).

If **LOC** is set to **REMOTE** (machine remote control), move cursor to **LOC** and press **ENTER**; label will change to **LOCAL**, i.e. local control operation mode.

In the same menu, ensure that power limiting is disabled: if **PWR** is set to **OFF**, i.e. power output is disabled, move cursor to **PWR**. Press **ENTER** and label will switch to **ON**, i.e. power output enabled.

Press **ESC** twice to go back to the **default menu** (menu 1).

- 3) Fine tune power setting from menu 2 (see description of item 1b) until achieving the desired value.



WARNING: Machine is capable of delivering more than rated output power (3500 W); however, never exceed the specified power rating.



NOTE: Exciter drive power setting should never exceed 30W, or it will trigger an Overdrive Alarm.



NOTE: If power is set to 0 W in the **edit mode**, the INTERLOCK OUT contact trips and external exciter power is immediately inhibited.

Next, you can review all operating parameters of the machine through the management firmware.

Normally, the machine can run unattended. Any alarm condition is handled automatically by the safety system or is signalled by the LED indicators on the panel or by display messages.



NOTE: Standard factory settings are: output power set to upper limit (unless otherwise specified by customer) and **OFF**.

5.4 Management Firmware

The machine features an LCD with two lines by 16 characters that displays a set of menus. Figure 5.2 below provides an overview of machine menus.

The symbols listed below appear in the left portion of the display as appropriate:

- (Cursor) - Highlights selected (i.e. accessible) menu.
- ▶ (Filled arrow) - Editable parameter marker. This symbol appears in menus that take up more than two lines to aid browsing.
- ▶▶▶ (Three empty arrows) - Parameter is being edited.
- ▶ (Empty arrow) - Current line marker; the parameter in this line cannot be edited. This symbol appears in menus that take up more than two lines to aid browsing.




Figure 5.2

When the display is off, touching any key will turn on backlighting.

When the display is on, pressing the **ESC** button from the **default menu** (menu 1) calls up the **selection screen** (menu 3), which gives access to all other menus:

```

Fnc Pwr P.A Alm
Mix Urs
  
```

Menu 3

To gain access to a submenu, select menu name (name is highlighted by cursor) using button  or  and press the **ENTER** button.

Press **ESC** again to return to the **default menu** (menu 1).

5.4.1 Operation Menu (Fnc)

In this menu, you can set **power output** On/Off, toggle between “Local” or “Remote” control mode and set the **Forward Power Good (PgD)** threshold rate.

To edit an item, highlight the appropriate line using the UP and DOWN buttons and then press and hold the **ENTER** button until the command is accepted. This way, Pwr setting is toggled between On and Off and Mod setting is toggled between “x1” and “x10”. To edit the Power Good rate, simply select item “PgD” and edit its value using buttons \leftarrow and \rightarrow ; finally, press **ENTER** to confirm.

```

▶Pwr : ON
  Loc : REMOTE
  Pg1 : 50      %
  Pg2 : 50      %
  Pg3 : 50      %
  Pg4 : 50      %
    
```

Menu 4

- | | |
|-----|---|
| Pwr | Enables (ON) or disables (OFF) amplifier power output. |
| Loc | Modifies machine operation. In the LOCAL mode, the machine can read and modify its operating parameters through the navigation keys and the management firmware, whereas all other sources are locked out. In the REMOTE mode, the machine can only read its operating parameters; parameters are modified based on the commands received from other connected telemetry systems. |
| Pg1 | Modifies Power Good (forward power) threshold. The Power Good rate is a percent of machine rated power (3500W for PJ35000LCD), not of forward output power. This means that this threshold set at 50% will give 1750 W regardless of set power level. The Power Good feature enables output power control and reporting. When output power drops below set Power Good threshold, the equipment changes the state of pin [9] of the DB25 “Remote” connector located on the rear panel. |
| Pg2 | Like Pg1, modifies a second Power Good threshold for forward power. When output power drops below set Power Good threshold, the equipment changes the state of pin [22] of the DB25 “Remote” connector located on the rear panel. |
| Pg3 | Like Pg1, modifies Power Good threshold for reflected power. When output power drops below set Power Good threshold, the equipment changes the state of pin [18] of the DB25 “Remote” connector located on the rear panel. |
| Pg4 | Like Pg1, modifies a second Power Good threshold for reflected power. |

5.4.2 Power Menu (Pwr)

This screen holds all readings related to machine output power:

Fwd:	0	W
Rfl:	0	W
InP:	12.3	W

Menu 5



Fwd Forward power reading.

Rfl Reflected power reading.

Inp Input power reading.

Note that these are readings, rather than settings, and cannot be edited (note the empty arrow). To change power setting, go to the **default menu** (menu 1) as outlined earlier.

5.4.3 Power Amplifier (P.A) Menu

This screen is made up of four lines that can be scrolled using the buttons  and , shows the readings relating to final power stage:

Vpa:	50.2	V
Ipa:	32.9	A
Eff:	57	%
Tmp:	27.8	°C

Menu 6

Note that these are readings, rather than settings, and cannot be edited (note the empty arrow).

VPA Voltage supplied to amplifier module.

IPA Current absorbed to amplifier module.

Eff Efficiency based on ratio of forward power to amplifier module power in percent (FWD PWR/(Vpa x Ipa) %).

Tmp Machine internal temperature.

5.4.4 Alarm Menu (Alm)

This menu shows any alarm conditions occurring during machine operation. Alarm thresholds are preset at the factory.

```

▶FWD:      0(10)
RFL:      0(10)
INP:      0(10)
Reset Alm
  
```

Menu 7

FWD	Conteggio delle situazioni di allarme dovuti a potenza diretta.
RFL	Conteggio delle situazioni di allarme dovuti a potenza riflessa.
INP	Conteggio delle situazioni di allarme dovuti a potenza in ingresso.
Reset Alm	Reset sulla numerazione delle situazioni di allarme.

Alarm conditions are numbered from 1 to 10 and reflect the following situations: forward output power too high, reflected output power too high and input power too high.

Alarm monitoring cycle is as follows: when an alarm condition is detected, alarm counter increases by 1 unit, machine goes into lock-out state and the display shows the cause for the stop. After 15 seconds, the machine attempts to re-start; if a new alarm condition is detected, cycle is repeated over and over again up to 10 times maximum.

If machine re-starts successfully, all alarm counters are reset after 30 minutes' regular operation. After 10 alarm conditions triggered by the same cause, the machine goes into fault lock-out mode, a lock-out mode warning appears on the display and the "FAULT/LOCK" LED turns on.

After the alarm condition has been rectified, the counter can be reset by highlighting "Reset Alm" and holding down the **ENTER** key for some time.

5.4.4.1 Alarms e Faults

There are three types of alarms that can cause a machine lock-out and trigger a "FAULT/LOCK" indication. **When any one of the three alarm thresholds is exceeded, the system will automatically switch to the warning screen (even though the user is browsing system menus) and the following messages are displayed:**

1. Over Forward Power

Forward power threshold exceeded.



!! ATTENTION !!
OVER FWD Power

Alarm 1

2. Over Reflected Power

Reflected power threshold exceeded.



!! ATTENTION !!
OVER RFL Power

Alarm 2

3. Over Input Power

Input power threshold exceeded.



!! ATTENTION !!
OVER INP Power

Alarm 3

Monitoring cycle is as follows:

- An alarm condition occurs;
- Alarm is displayed and device is locked out for 15 sec.;
- Operating conditions are restored;
- Verification.

Upon reaching the 10 cycle limit, a “FAULT/LOCK” indication is triggered and the device goes into lock-out mode; the appropriate LED turns on (figure 6.1) and this screen is displayed:

I. Over Forward Power

Forward power alarm display.



!! HALTED FOR !!
OVER FWD Power

Stop 1

II. Over Reflected Power

Reflected power alarm display.

```
!! HALTED FOR !!
  OVER RFL Power
```

Stop 2

III. Over Input Power

Input power alarm display.

```
!! HALTED FOR !!
  OVER INP Power
```

Stop 3

Once the machine goes into “FAULT” mode, it will no longer attempt to re-start; choose the appropriate reset procedure according to current machine setting:

- Machine set to LOCAL control mode - press “Reset Alm” in the alarm menu (menu 7) or power off and back on again using the **POWER** switch.
- Machine set to REMOTE control mode - power off and back on again sending the appropriate command via the DB25 connector (pin [8] and [20]).

There is a fourth alarm that does not trigger a “FAULT” condition, but allows some time until correct operating conditions are restored. When the temperature alarm threshold is exceed (about 85°C), the following screen appears:

4. Over Temperature

Temperature power threshold exceeded.

```
!! ATTENTION !!
OVER TEMPERATURE
```

Alarm 4

5.4.5 Miscellaneous Menu (Mix)

This menu lets you set machine address in an I²C bus serial connection:




▶ IIC: 255

Menu 8

IIC I²C address setting. The I²C network address becomes significant when the exciter is connected in an RVR transmission system that uses this protocol. Do not change it unless strictly required.

5.4.6 Version Menu (Vrs)

This screen holds machine version/release information:



▶ Rel:FPR0-000304
Dat:02/03/2005
Tab:PJL_02KL_01

Menu 9

Note that these are readings, rather than settings, and cannot be edited (note the empty arrow).

Rel	Firmware release information.
Dat	Release date.
Tab	Shows table loaded in the memory.

6. Identification and Access to the Modules

The **PJ3500LCD** is made up of various modules linked to each other through connectors so as to make maintenance and any required module replacement easier.

6.1 Upper view PJ3500LCD

The figure below shows the upper view of the machine with the various components pointed out.




Figure 6.1

- [1] DB15 filter Card
- [2] Bias Card
- [3] LPF Card
- [4] Panel Card
- [5] Telemetry Card
- [6] Com-Bus Card
- [7] Impeller FAN1
- [8] Impeller FAN2
- [9] PWR Input Measure Card
- [10] Splitter Card
- [11] RF amplifier Card
- [12] Fuse Card
- [13] Combiner Card

6.2 Lower view PJ3500LCD

The figure below shows the lower view of the machine with the various components pointed out.




Figure 6.2

- [1] Impeller FAN1
- [2] Com-Bus Card
- [3] Telemetry Card
- [4] Impeller FAN2
- [5] PS Interface Card
- [6] Interfaccia Card and Fan Control
- [7] Power Supply Interface Card
- [8] Power Supply Modules

7. Working Principles

The figures below provide an overview of **PJ3500LCD** (fig. 7.1) modules and connections.




Figure 7.1

Following is a brief description of the different module functions; all diagrams and board layout diagrams are included in the “Technical Schedule” Vol.2.

7.1 Panel Board

The panel board accommodates the microcontroller that runs the machine control software and all user interface elements (display, LED's, keys, ...).

This board is interfaced with other machine modules via flat cables and provides for power supply, control signals and measurement distribution.

7.2 Interface Board

This board performs the following tasks:

- It uses AC voltage to generate and distribute service power supply over the panel board;
- It controls and provides interfacing of the mains surge protection module;
- It controls and provides interfacing of the power amplifier supply module;
- It processes and provides interfacing of the control signals to/from the Bias Board;
- It processes and provides interfacing of the control signals to/from the Panel Board.

- It feeds and operates the cooling fans.

7.3 External Telemetry Board

This board provides an I/O interface for the CPU with the outside environment. All available machine input and output signals are brought to the REMOTE DB15 connector.

Also mounted on this board is the INTERLOCK IN BNC connector which can disable device power output. When the central pin is closed to ground, output power is limited to zero until ground connection is removed.

7.4 PWR Input Measure Board

This card makes two check and measure functions:

- Input power measure, measure send to interface card that supplies to send machine in protection mode in case of input power excess.
- Temperature measure.

7.5 Power supply

The **PJ35000LCD** power supply sections is made up of two basic sections: Service and Power Supply, that provide adequate power to the RF power amplifier modules.

The unit has a rectifier (PFC) able to ensure a $\cos \phi$ of 0.998 and a switching power supplies which allow an efficiency of 90%.

7.7 Power Amplifier

The RF power amplification section consists in several power modules (four on the **PJ3500LCD**) coupled through a Wilkinson splitter and combiner using stripline technology.

Each RF module of the **PJ3500LCD** provides 900 W rated power using a single active element built using LD-MOS technology. RF modules are fed by the switching power supply via the Bias board.

The splitter splits the incoming power input signal equally to all RF modules. The combiner combines the power output signals available at module outputs to obtain total amplifier power.

Splitter, amplifiers and combiner have been designed to sum amplifier output power signals in phase, so as to keep unbalance and power dissipation to a minimum.

The whole RF section is mounted on a finned heat sink with fan cooling.

7.8 LPF Card

This card is a low-pass filter and its function is to suppress the harmonic components generated by the amplifier below the levels required by regulations.

Moreover, in the end of filter, there is a directional coupler, its function is the measurement of the forward and reflected output power.

On this card there is an RF sample at -60 dB compared with the output and it is available on a BNC connector. This sample is useful for checking the characteristics of the carrier, but not of the higher order harmonics.

The filter also has a high-pass filter section that sends the third harmonic generated by the final stage to a termination of 50 Ohm 250 W (mounted in proximity of the driver); this method allows to maintain a sufficiently high efficiency even in case of presence of SWR in the antenna.

7.9 BIAS Card

The main purpose of this board is to control and correct the bias voltage of the RF amplification section MOSFETs.


It also provides a measure of the total current drawn by the RF modules and incorporates a dedicated circuit for power supply fault reporting.

Under normal conditions, bias voltage is adjusted according to set output power using feedback based on actual output power reading (AGC).

Abnormal conditions affecting bias voltage so as to trigger foldback current limiting are:

- Reflected output power too high
- External AGC signals (Ext. AGC FWD, Ext. AGC RFL)
- Temperature too high
- Current draw of one RF module too high

This page was intentionally left blank





R.V.R. Elettronica S.p.A.

Via del Fonditore, 2 / 2c

Zona Industriale Roveri · 40138 Bologna · Italy

Phone: +39 051 6010506 · Fax: +39 051 6011104

e-mail: info@rvr.it · web: <http://www.rvr.it>

ISO 9001:2000 certified since 2000



The RVR Logo, and others referenced RVR products and services are trademarks of RVR Elettronica S.p.A. in Italy, other countries or both. RVR ® 1998 all rights reserved.
All other trademarks, trade names or logos used are property of their respective owners.